



AmosConnect™ 8

IsatPhone Pro data service - setup guide

This factsheet will explain the steps necessary to use AmosConnect 8 over the IsatPhone Pro Data service.

Step 1: Install modem drivers

Connect your IsatPhone Pro handheld and install the modem drivers as per the instructions provided on the IsatPhone Pro Installation CD.

The latest firmware and drivers can be downloaded from: inmarsat.com/services/IsatPhoneProInmarsat

Step 2: Identify COM-port

Identify the modem COM port to which your phone is connected for the data service. The COM port number will be needed when you are using your data application. To do this, on your PC go to Control Panel > Phone and Modem Options and select the Modem tab. You will see IsatPhone Pro Modem and the COM port e.g. COM6. **OR** go to Control Panel > System and select the Hardware tab. Click on Device Manager and scroll down to Modems. If your USB drivers are installed you will see IsatPhone Pro Modem. Right click on the IsatPhone Modem and select Properties. You will see the COM port e.g. COM6.

Step 3: Configure AmosConnect 8

To configure the IsatPhone Pro for AmosConnect 8, simply add it as a new terminal. To do this, go to the Settings page of AmosConnect 8.

From here select Terminal Management and click the Add New Terminal button.

Terminal Management

Terminal Name	Type
Thrane & Thrane Sailor 250 FleetBroadband	Broadband/IP 127.0.0.1 edit

[Add New Terminal](#)
[Scan for New Terminals](#)

For the Terminal Type, select Legacy/Serial. In the next screen select the IsatPhone Pro from the Terminal Model dropdown. The correct details for this terminal will be filled in.

Add Terminal

Terminal Model: IsatPhone Pro

Terminal Name: IsatPhone Pro

Device: --choose--

Speed: 2400

Setup String: &FE0&D2

Disable modem speaker
 Dial without checking dialtone

For Device, select the COM-port identified in step 2.

Important Note: Older versions of the AmosConnect 8 software did not include this Terminal profile. The latest version as well as updated terminal libraries can be downloaded from: www.stratosglobal.com/amosconnect

For the Connection Details, you only need to fill in the Connection Name. The correct dial Number ('65') has already been filled in and the Prefix and Suffix are not necessary.

Add Connection

Terminal: IsatPhone Pro

Connection Name: IsatPhone Pro

Prefix:

Number: 65

Suffix:

Step 4: Connect

You are now done setting up the terminal. To ensure that AmosConnect 8 uses the IsatPhone to dial out for email exchange please go to Settings -> Mail Administration -> Configure Send/Receive Defaults and select the IsatPhone Pro as the default Connection Profile.

Default Send/Receive Options

Default connection profile... ▼

Now you can click Send/Receive from the Home screen or from Mail Administration. The IsatPhone handset will dial out to the AmosConnect hub and exchange messages.

Quick tip: You can also configure a schedule for connections under Settings -> Mail Administration -> Configure Send/Receive Defaults:

Scheduled Connection

Connect on the following schedule:

Days (0-6, 0=Sunday):

Hours (0-23):

Minutes (0-59):

Connect on schedule only when message queued

Examples:

- [every 10 minutes](#)
- [every hour](#)
- [once every day at 1AM](#)
- [once every weekday at 1AM](#)

This will ensure that AmosConnect 8 dials out on the configured schedule automatically.

Call: 1 800 563 2255 (North America)
Call: +1 709 748 4226 (worldwide)
Email: help@inmarsat.com
www.inmarsat.com